



Beacon Graphic Systems
189 Meister Avenue
Branchburg, NJ 08876
www.BeaconGraphics.com

800 762-9205 • FAX 908 231-8943



DIRECTIONS for Methylene Chloride Solvent

1. Moisten inside of garment behind lettering with Solvent. Use either a clean, light colored cloth or Solvent Dispenser. Apply to one or two letters at a time. Large numbers can be removed a portion at a time.
2. Allow at least 20 seconds for Solvent to loosen adhesive from the fibers of the garment. Solvent evaporates rapidly, so you may have to remoisten garment.
3. Pull off letter slowly.
4. If any adhesive residue remains on the garment, remove it by using Solvent the same way you would use a spot remover. Turn cleaning cloth frequently. An alternate method to remove any residue is place a sheet of Silicone Paper over the spot and reheat the garment on your heat seal machine for 10 seconds. Discard silicone paper after use.

SUGGESTIONS:

Test solvent on garment for fading or damage to synthetic fabrics. If spotting occurs, feather edges with Solvent. Keep can tightly capped to prevent evaporation.